

RV PLEATED SHOWER DOOR INSTRUCTIONS PFSD-3657 THRU PFSD-6067

Tools Needed:

- Philips Screwdriver
- Miter or Hacksaw
- 100% Silicone Caulk
- Measuring Tape
- Silicone Spray (Optional)

Shower Door Includes:

- 1 Bottom Rail
- 1 Side Rail
- 1 Door Assembly
- 1 Top Track & Aluminum Channel Insert
- 1 #6 x 1-½" Screw

A. Mount Bottom Rail

1. Measure the distance between the left and right walls along the bottom of the tub/shower.
2. Cut the bottom rail to the size measured in Step 1.
3. Peel the paper backing from the bottom rail.
4. With the drain slots facing toward the inside of the tub shower, press the rail to the tub/shower.
5. Caulk the inside edges of the bottom rail at the walls using 100% silicone caulk.

B. Mount Door Assembly

1. Peel the paper backing from the door assembly.
 2. Press the door assembly against the sidewall of the tub/shower.
- IMPORTANT:** Make sure the door assembly is vertical and rests inside the bottom track with the notches facing up, and the bottom of the side rail is pressed into the corner of the bottom rail and silicone.

C. Mount Side Rail

1. Peel the paper backing from the side rail.
2. Press against the side wall opposite the door assembly making sure the notches are facing up, and the bottom of the side rail is pressed into the corner of the bottom rail and silicone.

D. Mount Top Track

1. Measure the distance between the left and right walls at the top of the side rail.
2. Cut the top track with a hack saw or miter to the size measured in Step 1.
3. Peel the paper backing from the tabs at the top of the side rail and from the door assembly - four tabs.
4. Slide the aluminum insert 3" out of the left side of the top track.
5. Slide the aluminum channel over the plastic carriers.
6. Slide the top track over the shower door assembly and over the top of the side rail.
7. Spread the top track just above where it slides over the side rail and door assembly when pushing the top track into place over the adhesive tape tabs.
8. Make sure the top track is pressed down firmly into the side rail slots.
9. Caulk all edges inside and outside of the tub/shower for best results.

E. Mount Ball Catch

1. Insert the #6 x 1-½" screw into the mount ball catch.
2. It is important that the ball catch is lined up evenly with its hole in the shower door.
3. Drive the screw into the side rail securing the ball catch. The strap holds the door open. **HINT:** Position the male strike at or slightly (1/16") above the position of the ball catch.

For optimal curtain opening/closing, apply a thin layer of silicone spray to the inside of the top track. (optional)



Step A



Step B-C



Step D-5



Step D-7



Step E